ASSEMBLY INSTRUCTION

PATIO FURNITURE SETS



N704P210021; N704P210023; N704P210026 N704P210028; N704P210029

Notice:

- 1. 50% Tighten before fixing all screws, Allen wrench is recommended instead of an electric drill.
- 2. Place the item on a flat ground to adjust and make sure it remains stable.
- 3. Tighten up all screws with tools gradually.
- 4. If the screws are not aligned with holes during assembly, please loosen all the other screws to 50% and continue the assembly process.
- 5. If the item is not stable, please loosen all the screws, adjust it on a flat ground and tighten up all screws again.
- 6. Note : If one or some screws are fully tightened during assembly, chances are the others will not be aligned with holes. In addition, all the holes are designed to be relatively larger to provide more space for the adjustment of the screws.























Connect the part from step (1) & Small Table Top (C) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Connect the part from step (2) & Side Small Table Face (E) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Firmly, tighten all Bolts and Put the Table upright. Set the glass (A) to finish Small Table.



Tighten the Adjusting Leg (1) & Big Table Leg 1 (H1), (H2), (H3).



Connect the part from step (5) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).







Connect the part from step (7) & Angle Connector (6) by tighten Bolt (2), Flat Washer (5) with Allen Key (7).

50%







Connect the part from step (9) & the part from step (6) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Firmly, tighten all Bolts and Put the Table upright. Set the glass (B) to finish Big Table

STEP 12



Set nesting two Table.



Tighten the Adjusting Leg (1) & Stool Leg (T1).



Connect Front Side Stool (K) & Curve Side Stool (L) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).





Connect the part from step (15) & Behind Side Stool (M) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Firmly, tighten all Bolts and Put the Stool upright. Set the cushion (Y) to finish Stool.



Connect Armless Bench Seat (N) & Armless Bench Back (O) by tighten Bolt (4), Flat Washer (5) with Allen Key (7).



Connect the part from step (20) & Armless Bench Front Side (P) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Connect the part from step (21) & Side Bench (R), (S) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).





Connect the part from step (22) & the part from step (19) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Firmly, tighten all Bolts and Put the Bench Armless upright. Set the cushion (Z), (X2), (X3) to finish Bench Armless.



20-26



Connect the part from step (26) & Big Corner Bench Back (U2) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Connect the part from step (27) & Corner Bench Seat (Q) by tighten Bolt (4), Flat Washer (5) with Allen Key (7).



Connect the part from step (28) & Front Side Corner Bench (V) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Connect the part from step (29) & Left Side Bench (S) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Connect the part from step (30) & the part from step (25) by tighten Bolt (3), Flat Washer (5) with Allen Key (7).



Firmly, tighten all Bolts and Put the Corner Bench upright. Set the cushion (Z), (X2), (X3), (X1) to finish Corner Bench.



Set the finish Sofa 1.

STEP 34



Set the finish Sofa 2.



Set the finish Sofa 3.

STEP 36



Setting the finish Sofa 1 or Sofa 2 for storage with the Cover



Setting the finish Sofa 3 for storage with the Cover



Set the Cover (W) to protect The Set.