

# Homax Spray Spackling



## DIRECTIONS FOR USE:

PREPARE SURFACE BY LIGHTLY SANDING AROUND THE HOLE AND WIPING CLEAN.

FOR HOLES LARGER THAN 2" APPLY A WALL PATCH (SOLD SEPARATELY) OR MESH JOINT TAPE FOR SMALL CRACKS AND HOLES.

FOR BEST RESULTS, PRIME/SEAL AREA AFTER APPLYING SPACKLING.

1. Shake can vigorously for one full minute.
2. Hold can vertically-approximately 6-12" away.
3. Cover entire wall patch or mesh tape area completely with several thin coats, smoothing with a drywall knife between coats. Build the spackling progressively. Apply less material around perimeter of patch to blend with existing surface.
4. Let dry and then lightly sand. Repeat if necessary.
- 5.

**TIP:** Apply Homax® texture if needed, prime and paint or apply wall paper.

**\*COVERAGE:** Will cover two 4"x 4" wall patches.

**DRY TIME:** 2-4 hours for shallow or small repairs.  
24 hours for wall patches or larger holes.