



# GRONOMICS® “TOOL FREE ASSEMBLY”

## 18” x 48” PLANTER BOX Parts Check List and Assembly Instructions

### STEP I

- A) Unpack all of the parts and organize them in ‘like’ stacks. Please read the instructions in its entirety before beginning assembly.

### You should have:

Model #PB18-48

| QUANTITY                                | PART DESCRIPTION                           | PART #      |
|---|--|-------------|
| 4                                       | 4” x 4” x 19” Corner Post                  | 1900        |
| 4                                       | 4” x 4” x 1½” Post Cap                     | 3100        |
| Parts for the Sides                     |  |             |
| 4                                       | 14½” x 5½” x 1” Side Rail                  | 1450        |
| 2                                       | 14½” x 2½” x 1” Narrow Center Side Rail    | 1451        |
| 2                                       | 45” x 5½” x 1” Side Rails w/Cleat          | 7011        |
| 2                                       | 45” x 2½” x 1” Narrow Center Side Rail     | 4502        |
| 2                                       | 45” x 5½” x 1” Side Rail (One w/Logo)      | 4501, 4501L |
| Parts for the Bottom                    |  |             |
| 2                                       | 15” x 5½” x 1” Corner Notched Bottom Board | 1552        |
| 6                                       | 15” x 5½” x 1” Bottom Board                | 1550        |
| 1                                       | 18” x 48” Fabric Liner                     | 2003        |
| Packaged & Inspected by:_____ Date_____ |  |             |

**NOTE:** If you need assistance with parts or have assembly questions, please contact Customer Service either via email at [info@cwpmulch.com](mailto:info@cwpmulch.com) or phone at 763-753-7374.



# GRONOMICS® “TOOL FREE ASSEMBLY”

## STEP II

- A) Start by standing up two of the four 4” x 4” x 19” posts.
- B) Slide a 45” x 5½” x 1” side rail with cleat on bottom between the posts. (see figure 1)
- C) Repeat the same process with the other two 4” x 4” x 1” posts and 45” x 5½” x 1” side rail with cleat.

**Soil depth options:** The directions as printed will provide a planter box with a soil depth of approximately 10”. If you want a soil depth of approximately 6”, just reverse the position of the lower side rail with the cleat on top.

(Figure 1)



## STEP III

- A) Connect the two sets of corner posts by sliding a 14½” x 5½” x 1” side rail into each post. (see figure 2)

(Figure2)



## STEP IV

- A) Slide both of the 45” x 2½” x 1” narrow center rails between the posts on both ends. Do the same with the two 14½” x 2½” x 1” narrow center rails.
- B) Repeat step IV using the last two 45” x 5½” x 1” side rails and the 14½” x 5½” x 1” side rails. Note: Placement of the 45” x 5½” x 1” side rail w/logo. (see figure 3)

(Figure 3)



## STEP V

- A) Place the two 15½” x 5½” x 1” corner notched bottom boards on the end cleats. Make sure the corner cut-out notches are in the corners.
- B) Place the remaining 15 x 5½” x 1” bottom boards on the cleats.

## STEP VI

- A) Carefully remove the screw covers that are protecting the cap screws. Place the cap on the center of the screw utilizing the pre-drilled hole in bottom of the cap. - Do not over tighten. (see figure 3)
- B) Place the fabric liner on the bottom.

**Recommended Finish:** A natural oil non film-forming finish designed for Cedar. If Cedar is not finished checking may occur and will naturally turn a weathered gray color.

**1-Year Warranty:** All Gronomics® products are warranted against all manufacturing defects of material or craftsmanship for a period of ONE full year from date of purchase. Warranty does not cover cracking, damage caused by negligence, alterations or abuse in any way.