

installation instructions:

BRACKETS & CORBELS

SAFETY INSTRUCTIONS

Make sure to use the correct tools recommended.

Wear safety goggles.

Follow fixture, power tools, and paint manufacturers' instructions and users manuals.

Use common sense and follow good construction practices.

Medallions are not load bearing. Do not use them to support electrical fixtures or ceiling fans.

TOOL & MATERIAL CHECKLIST

- construction adhesive
- elastomeric adhesive caulk
- caulking gun
- nail gun
- finishing nails
- extra fine sandpaper
- putty knife

IMPORTANT INFO

- It is highly recommended that you paint/finish our brackets or corbels before you install them.
- Once installed, you can apply any necessary touchup paint/finish.
- Clean installation surface and back of bracket of all dirt and dust with a clean cloth or sponge.
- Make sure that the surface and the back of the bracket are completely dry before attempting installation.
- Measure and mark the location where the bracket is going to be installed.

INSTALL INSTRUCTIONS:

1. Lay the bracket or corbel face down on a soft surface that will not scratch/dent the bracket detail.
2. Apply a 1/2" bead of adhesive caulk all the way around the back edge of the bracket.
3. When pressing the bracket up against the surface, some adhesive caulk will seep out. Smooth excess caulk around the bracket with a finger or the putty knife and apply extra caulk that is needed to fill in any gaps.
4. Wipe off any excess adhesive caulk with a sponge or damp rag.
5. Finishing nails may be used for added support. If used, fill in any nail holes with caulk and smooth the surface with a finger. Let any excess caulk dry. Once dry, lightly sand with extra fine sandpaper.
6. Touchup bracket with touchup paint as needed

EXAMPLE DIAGRAM:

