



1. Remove all components from the strainer body.
2. Apply a small amount of putty evenly around the top hole in the sink, approximately 1/2" from the opening.
3. Insert the basket strainer into the sink opening. Slip the rubber and paper washers up to the sink. Thread and tighten the lock nut onto the washers.
4. Place the poly washer on the tailpiece extension. Connect the tailpiece to the strainer with the slip nut. Tighten it securely to the strainer. Test for leaks by running water.