

INSTASET QUICK INSTALLATION GUIDE

TOOLS YOU'LL NEED:

- RAZER KNIFE
- GROUT FLOAT
- TAPE MEASURE
- PENCIL
- LEVEL
- PRY BAR
- TILE SPACERS (OPTIONAL)
- GROUT (OPTIONAL)

STEP 1 SURFACE PREPERATIONS:

- Wall/substrate must be free of any debris, dust, and/or loose paint.
- Wall must be leveled, non-porous, smooth, dry and flat.
- Wall/Substrate can be laid over an existing tile surface, as long as it meets the substrate requirements above.

STEP 2 MEASURE THE WALL

Using a tape measure, pencil, ruler and level (if needed), mark out the measurements of your space.

STEP 3 ADHERE ADHESIVE MEMBRANE TO WALL

- Roll out the adhesive onto the wall (inner side facing the wall). We recommend rolling the roll out in a vertical direction for a strong bonding (top to bottom).
- Follow any markings made previously to ensure a straight line. Repeat process with the entire wall.

STEP 4 OUTLETS/FAUCETS/SHOWER HEADS

- Using a razer knife, carefully cut through any openings and remove the excess adhesive.

STEP 5 FIRMLY PRESS DOWN

- Using a grout float, firmly press down the adhesive.

STEP 6 CLEAN THE TILE

- Using a clean rag, wipe down the back of the tile/mosaic. Make sure the backing of the tile/mosaic is dry and smooth.
- Tile should be as flat as possible.
- Must achieve >80% direct bonding to the adhesive.

STEP 7 PEEL

- Peel the top protective layer of the Instaset membrane to expose the front facing adhesive.

STEP 8 STICK

- Following the lines drawn previously, gently press the tile onto the adhesive. Use a pry bar for adjustments/repositioning when needed.
- Firmly press the tile into the wall to secure bonding.

STEP 9 GROUTING (OPTIONAL)

- Grouting may be optional depending on the usable and application. Check with the tile manufacturer's guideline for more details.



FIND MORE INSTASET RATED TILE PRODUCTS ON GBMGLASS.COM

FOR MORE DETAILED INSTALLATION TIPS, SEARCH "INSTASET TILE ADHESIVE" ON YOUTUBE.COM

**HAVE QUESTIONS? CALL US
1 (888) 862-8397**