

Prior to installation, please review the instruction manual located inside the product packaging.

Tools and Materials Needed

- PE film • underlayment items • aluminum self-adhesive joint tape
- spacer wedges • wood/white (PVAc-based) glue D3 • saw
- pencil • folding ruler • chisel/pry bar • moist wipe

