



ASSEMBLY INSTRUCTIONS FOR DECK KIT 44306

Take the two (2) different bottom support brackets and line up with frame mounts on the Chore Warrior chassis. Attach using hardware and hand tighten.



Attach the Mesh Deck to the support brackets with hardware, having the (4) holes at the one end of the deck flush up against the handles. Using the U-bolts attach the deck to the handles. Hand tighten only at this time.



Stand the Deckbarrow up on the dump brace or work from underneath, with the battery removed for access. Center the support brackets to the chassis and tighten.

Tighten the mesh deck bolts to the support brackets.

Re-route throttle wiring, keeping the throttle wiring from getting pinched between any attaching hardware or frame! Tighten the U-bolts to the handles.

