



INSTRUCTIONS:

1. Install to wall studs or wooden side walls.
2. Measure a minimum of 12 inches from back wall and the appropriate height from the ground for placement of your rod support sockets. Mark around the edge of each socket with a pencil. Note the left-side socket height must equal the right-side socket height to ensure a level rod.
3. Drill the 3/32-in pilot holes using the socket as a template.
4. Use a Phillips screwdriver to fasten each socket to the wall (screws included).

INSTRUCCIONES:

1. Instale en montantes de pared o paredes laterales de madera.
2. Mida un mínimo de 30,48 cm desde la pared posterior y la altura adecuada desde el suelo para colocar los soportes de la varilla. Marque alrededor del borde de cada soporte con un lápiz. Tenga en cuenta que la altura del soporte del lado izquierdo debe ser igual a la altura del soporte del lado derecho para garantizar una varilla nivelada.
3. Taladre los orificios guía de 2,38 mm (3/32") con el uso del soporte como plantilla.
4. Utilice un destornillador Phillips para fijar cada soporte a la pared (se incluyen los tornillos).

