



Alpine Industries
27 Selvage St.
Irvington, NJ 07111
Tel: 973 601 5105
Fax: 973 854 8650

Sanitary Napkin Receptacle

Item# 451-WHI/451-BLA/451-PNK/451-PUR

Installation

1. Please choose a vertical, clean and smooth mounting surface.
2. Make sure there is enough room above dispenser to open the cover.
3. Open the top cover and use the back plate for the drill marks for the 2 top and 1 bottom drill locations.
4. Drill 3 holes.
5. Insert 3 plastic anchors (not supplied) into drilled holes.
6. Mount sanitary napkin dispenser on bottom screw with washer.
7. Remove inner liner.
8. Fasten top screws with washers through the slots at back plate, and replace inner liner.