

Cinch™ Installation Instructions

Steps to Install Top & Sides

1. Remove existing door weather stripping, ensuring the removal of any residue.
2. Clean door surface with a solution of 50% isopropyl alcohol and 50% water.
3. With the door closed, use one (1) 42" piece to compress the vinyl bulb against the door ensuring complete seal. Slowly peel film backing away from Cinch™ and press lightly as you continue peeling away the backing and pressing onto the door jamb. Once in place, apply firm and consistent pressure along the length of the door jamb to adhere.
4. Measure distance between the top of the installed 42" piece and the top of the door.
5. Cut the door jamb to match measurements using a hacksaw.
6. Cut the supplied vinyl connector in half. One of the halves will be used on the left side of the door and the other on the right.
7. Place one of the vinyl connectors in the vinyl bulb of the Cinch™ you have already installed leaving half of it exposed.
8. Take the cut jamb and insert the remaining portion of the vinyl connector into the vinyl.
9. With the door closed, compress the vinyl bulb against the door ensuring a complete seal. Slowly peel film backing away from Cinch™ and press lightly as you continue peeling away the backing and pressing onto the door jamb. Once in place, apply firm and consistent pressure along the length of the door jamb to adhere.
10. Repeat steps for the top and the other side.



QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

