



AN ORIGINAL GRANITE BRACKET™ PRODUCT THE ORIGINAL™ T-BRACKET



1. Mark 2"-4" from the outer edge of the the cabinet for your first notch to be cut. Then set marks for the remaining brackets every 16"-20" apart. With your brackets properly spaced, rout or chisel a 2.5" wide by 0.5" deep notch for each bracket.



2. Once your cabinet is notched, place your bracket within the notch, so as the bracket's vertical support is on the inside of the cabinet.



3. Once your brackets are in place and level, drill pilot holes through the holes on the bracket. Once pilot holes are made, drill the screws through the pilot holes, fastening the bracket to the inside of the cabinet.



4. Now that your brackets a properly secured and in place. Place the countertop of your choice on top.



5. With your countertop now resting upon the brackets, we recommend applying a bead of clear silicone adhesive around the brackets.



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

*AVAILABLE
IN MULTIPLE SIZES