

Align handrail bracket position, drill pilot holes,
then secure with 3 screws included.

