



BARN DOOR

STAY ROLLER GUIDE - BOTTOM

1. Measure thickness of door. Adjust stay roller guide to match door thickness plus 1/8".
 2. Using the stay roller guide as a template, place on ground against the structure roughly even with the door opening.
 3. Drill pilot holes, attach using included mounting hardware.
-

PUERTA DE GRANERO

GUÍA DEL RODILLO DEL SOPORTE INFERIOR

1. Mida el grosor de la puerta. Ajuste la guía del rodillo para que coincida con el grosor de la puerta más 1/8" (0.3 cm).
2. Utilice la guía del rodillo como plantilla y colóquela sobre el suelo contra la estructura, aproximadamente a la altura de la abertura de la puerta.
3. Perfore orificios piloto, fíjelo utilizando los accesorios de montaje incluidos.

QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

