

How To Measure Inside Mount Cordless Cellular Shades

Things to consider before purchasing : Check for obstacles and window sash depth.

Tool Needed : Note Paper / Pencil / Measuring Tape.

If your window has an obstacle check if there's enough depth of 1-3/4". If less than 1-3/4", proceed with Outside Mount Measurement.

Let's start Inside Mount Measurement.

Step 1: Measure For the Width

Measure the width inside the window frame at – top, middle, and bottom, to allow for variances in construction.

- Measure to the nearest 1/8 of an inch.
- Use the smallest measurement as the window width to make sure that the blinds clear the sides of the window frame.

Step 2: Measure For the Height

Measure the height inside the window frame at - left (h1), middle (h2), and right (h3), to allow for variance construction.

- Round the measurements down to the nearest 1/8 of an inch.
- Use the largest measurement as the window height so the shades cover the entire opening.

Step 3: Final Measurements

Measure the window diagonally.

- If the two diagonal dimensions differ significantly, it may be necessary to order outside-mounted shades for optimal light control and privacy.
- Measure the window area exactly.

Step 4: Place Order

- Round measurement DOWN to the closet available size for width.
- If your exact window height is not available, round UP to the next larger height.

