7236 PTB THERAPY TUB



INSTALLATION: Add 1/2" to 1" height of tub at point () to allow space for bedding compound. All Watertech Whirlpool Baths require mortar to be placed under tub for tub bedding. Please measure tub before building tub cabinet. Drawing shows standard pump location for this tub. Custom pump locations available - please call Watertech Whirlpool Baths for details. Measurements are plus or minus 1/2", and are subject to change without notice.

** Physical therapy tubs may require additional space beyond its top perimeter for installation. ALWAYS measure tub before building tub cabinet.