



UNIVERSAL POP DOWN® SINK DRAIN

for sinks with and without overflow

INSTRUCTIONS:

1. Disassemble the sink drain components
2. Apply silicone to the underside of the flange
3. Insert the flange into the sink drain recess
4. **A:** Thick Sinks¹: Use only one rubber washer
B: Thin Sinks²: Use two rubber washers and the spacer with the taper oriented down
5. Carefully screw the body onto the flange threads from below. Make sure the rubber washer(s) are correctly seated in the recess of the drain body

INSTALLATION TIP: If the bottom of the sink is coarse or manufactured out of cast iron, apply a small bead of silicone to the top of the rubber washer(s) to seal any imperfections/voids in the sink basin

6. Hand-tighten the drain body, compressing the sealant between the flange and sink basin (remove excess sealant)
7. Connect to the existing plumbing system
8. Insert the cartridge into the finished flange and test for leaks

INSTALLATION TIP: This drain features a single-piece tailpiece and body. For space-saving and/or to achieve an appropriate slope of the drainage system, trim the tailpiece using a hacksaw or plastic tubular cutter. Don't forget to chamfer the tailpiece to ensure a watertight seal.

¹Thick sinks are ½" or greater in overall thickness

²Thin sinks are less than ½" in overall thickness, such as a vessel sink, or glass basin

UNIVERSAL POP DOWN® DESAGÜE DE FREGADERO

Para fregaderos con o sin rebose

INSTRUCCIONES:

1. Desarmar los componentes del desagüe de fregadero
2. Aplicar silicona en la parte inferior de la brida
3. Insertar la brida en el hueco del desagüe de fregadero
4. **A:** Fregaderos gruesos¹: Usar sólo una arandela de caucho
B: Fregaderos delgados²: Usar dos arandelas de caucho y el espaciador con el ahusamiento mirando hacia abajo
5. Atornillar cuidadosamente la unidad en las roscas de la brida desde la parte inferior. Verificar que la(s) arandela(s) de caucho esté(n) correctamente asentadas en el hueco de la unidad de desagüe.

SUGERENCIA PARA LA INSTALACIÓN: Si la parte inferior del fregadero es áspera o hecha de hierro fundido, aplicar una pequeña gota de silicona en la parte superior de la(s) arandela(s) de caucho para sellar toda imperfección/espacio en el cuenco del fregadero.

6. Apretar la unidad de desagüe a mano, comprimiendo el sellador entre la brida y el cuenco del fregadero. (Remover el exceso de sellador)
7. Conectar al sistema de plomería presente
8. Insertar el cartucho en la brida acabada y hacer una prueba para verificar que no hayan fugas.

SUGERENCIA PARA LA INSTALACIÓN: Este desagüe tiene un cabo y una unidad de una sola pieza. Para ahorrar espacio y/u obtener una inclinación adecuada del sistema de desagüe, recortar el cabo usando una sierra o una cuchilla tubular de plástico. No olvidar de biselar el cabo para garantizar un sello hermético.

¹El espesor total de los lavabos gruesos es de ½" (1.27 cm) o más

²El espesor total de los lavabos delgados, tales como los lavabos sobre encimera o las piletas de vidrio, es menor que ½" (1.27 cm).