



NO-CAULK PREFORMED DRAINS

INSTRUCTION GUIDE



Oatey No-Caulk Shower Drains are designed with a drain body that seals to the shower base with washers. For use with preformed shower bases, these drains come with a universal snap-in strainer in a variety of finishes that complement your bathroom's existing décor. Oatey products have earned the trust of plumbing professionals for over 100 years.

1. Apply ½ in. bead of Oatey Plumber's Putty around the underside of the no-caulk barrel flange.
2. Place the no-caulk barrel through the top side of the shower base hole. Compress down as far as you can without twisting.
NOTE: Do not use plumber's putty on ABS drain bodies.
3. Place the rubber sealing washer and friction washer over the barrel to the underside of the shower base.
4. Tighten the locking ring using adjustable pliers.
5. Once fully tightened, remove any excess plumber's putty from the top of the drain.
6. Install shower base into final location.
7. Place the rubber pipe gasket bevel side up over the drainpipe coming up through the no-caulk barrel. Push down on the rubber pipe gasket until it sets at the bottom of the no-caulk barrel.
8. Thread the gasket set screw into place over the drainpipe with the provided wrench and tighten with a screwdriver.
9. Snap in drain cover.