

Align window sash bar lift on bottom rail of window, drill pilot holes, then secure with 4 screws included.

