



AN ORIGINAL GRANITE BRACKET™ PRODUCT

THE ORIGINAL™ SIDE WALL BRACKET



1. Open up your wall, exposing the wall studs beneath your window.



2. Place brackets between 16-20 inches apart, or where wall studs are available. Secure each bracket to the wall studs beneath the window sill. Ensure brackets are level and are aligned horizontally. Using the bracket holes as guides, drill pilot holes, and from there fasten the bracket to the wall studs with screws.



3. Once your brackets are securely in place and level, install sheet rock to your framing. Ensure there are 2.5 inch wide by 0.5 inch deep notches, to allow the brackets to fit through the sheet rock.



4. Now that your brackets are properly secured and in place. Place the countertop of your choosing on top of the brackets.



5. With your countertop now resting upon your brackets, we recommend applying a bead of clear silicone adhesive around the brackets.



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

*AVAILABLE
IN MULTIPLE SIZES