

Safety Precautions

Health Precautions: Product is water-based. As with any chemical construction products, exercise care when handling.

Safety Precautions: Use adequate ventilation. Safety goggles and protective gloves are recommended. Remove contaminated clothing immediately.

First Aid: SKIN CONTACT: Wash thoroughly with soap and water.

EYE CONTACT: Flush immediately with water for 10-15 minutes and contact a physician.

RESPIRATORY PROBLEMS: Remove affected person to fresh air immediately and contact a physician.

HYGIENE: Wash hands immediately after use. Wash clothing before re-use.

Spills: Collect with suitable absorbent material such as cotton rags.

Disposal: Dispose in accordance with local, state and federal regulations. Tuff-Wall is non-hazardous.

Applying Tuff-Wall

Work Area:

Apply to a clean dry surface. Remove loose debris, treat oil spots and fill large gaps before starting application.
(Fill gaps and holes with putty, grout or plaster depending on surface)

Protect work area:

Use paper, tape and drop clothes to protect floors, doorways, trim work and windows.

Opening & Mixing:

Open by pulling the pull tab on bucket and mix thoroughly, preferably using a mixing paddle with drill, if mixing paddle and drill not available mix with heavy clean stick.

1st Application:

Place a small amount of the product on hawk as needed. Using trowel, apply product to the surface in a thin skim coat until surface is covered (you should be able to see the surface under the first coat). Let the first coat set approximately 90 min. (more or less) until product is almost dry but still moist. To check for final coat: lightly touch the surface, the product should feel moist but not come off on your finger, if this is achieved you are ready for the final coat.

IMPORTANT

DO NOT LET PRODUCT COMPLETELY DRY BEFORE APPLYING SECOND COAT.

Final Application:

Hold trowel at a 30 degree angle, apply final coat in a thin smooth layer until surface is covered. After covering surface with the final coat you may or may not see trowel marks. If trowel marks are present clean trowel thoroughly then spray the trowel with soapy water (1-2 drops of soap) and lightly rub over the trowel marks until they are gone.

Wait until the product dries before removing paper and tape.

Your application is finished

Thank you for choosing Tuff-Wall a product of:

CG Manufacturing, LLC
601-264-8649 1-877-264-8649
www.tuff-wall.com