

Align brace position, drill pilot holes, then secure with 2 screws included.

