



INSTRUCTIONS:

1. To properly install a station, you will need a pair of pliers or socket wrench, a shovel, water, and a bag of quick setting cement.
2. Choose an area that is easily accessible and conspicuous. Dig a hole 12" to 14" deep. Be sure to check for underground utilities prior to digging.
3. Work the dog waste station pole into the hole so that it will stand on its own. Once you have the pole properly set, pour the quick setting cement into and around the base of the pole, then pour the water over the cement. This will activate the hardening of the cement and provide a good, solid foundation for your dog waste station.
4. Wait about 30-45 minutes for the cement to set and then begin insalling the various pieces fo your station.
5. Use a pair of pliers or socket wrench to secure the dispenser, sign and wastebasket to the pole with the provided bolts.