

MATERIALS: Post - Zinc die cast Ring - Steel

INSTALLATION: Mount wall plate bracket(s) per installation instructions with supplied fasteners. Slip

product over wall plate(s) and tighten set screws until secure.

## OPTIONAL FASTENER

INFORMATION: Wood blocking is preferable behind all wall surfaces. If wood blocking is not available, the

following fasteners are suggested: Tile/Masonry - Plastic or Lead Anchors, Plaster/Drywall

- Toggle Bolts.

SPECIFICATION: Surface mounted towel ring shall be model

(fill in model number) by Liberty Hardware Manufacturing Corporation.