

Align hinge position,  
drill pilot holes,  
then secure with  
8 screws included.

