



## **Embers Out Soffit & Foundation Vent Mounting Recommendations**

1. Check cavity size to ensure proper fit. Ideally there should be no more than 1/8" clearance all around between the vent body and the cavity.
2. Remove all dirt or other obstructions around the cavity that may prevent the vent flange from making good contact with the mounting surface.
3. Put a bead of sealant, approximately 3/6<sup>th</sup> in diameter all around the flange contact surface. Embers Out recommends using Quad Max sealant. This can prevent water or other unwanted entities from entering into the cavity.
4. Center the vent in the cavity and use the existing mounting holes in the flanges as a guide for attaching the vent to the structure. For all surfaces use the recommended procedures dictated by the building codes in your area.
5. Remove any excess sealant around the flanges.
6. If you painting is required, mask off the 1/8<sup>th</sup> hole pattern. Use only spray paint.