

Align bumper position,
pre-drill a hole,
insert wall anchor
if needed, then secure
with screw included.

