

## Hanging Instructions:

- 1. Place 1 piece of painters tape over the 2 brackets you've chosen
- 2. Poke holes in the tape where they cover the bracket cross.
- 3. Carefully remove the painters tape from the back of the mirror and place it on the wall where you would like to hang the mirror.
- 4. You will be able to see exactly where to place your screws.
- 5. Drill screws (included) and remove the painters tape from the wall.
- 6. Hang your mirror