



BARN DOOR

BOX RAIL - SPLICE BRACKET

1. Loosen the two bolts on top of splice bracket.
2. Slide splice brackets onto end of box rail, aligning top bolts with pre-drilled holes in box rails. Secure to box rail by tightening bolts.
3. Pre-drill hole in structure and mount splice bracket with 3/8" lag bolt.

Note: Ensure the splice brackets are being secured directly into a 2" x 8" header above door opening.

PUERTA DE GRANERO

SOPORTE DEL EMPALME DEL RIEL DE LA CAJA

1. Afloje los dos pernos en la parte superior del soporte del riel de empalme.
2. Deslice los soportes del empalme sobre el extremo del riel de la caja, alineando los pernos superiores con los orificios pretaladrados en los rieles de la caja. Asegúrelo al riel de la caja apretando los pernos.
3. Perfore un orificio previamente en la estructura y monte el soporte de empalme con un tirafondo de 3/8" (1 cm).

Nota: Asegúrese de que los soportes de empalme se aseguren directamente en un tablero superior de 2" x 8" (5 cm x 20.3 cm) sobre la abertura de la puerta.

QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

