



WINDOW FILM APPLICATION KIT

Easy Application Instructions

1. **Clean Glass** : Thoroughly clean window to edges and corners.
 2. **Trim Film** : Trim to fit to window leaving a $\frac{1}{16}$ " margin between film and window frame.
 3. **Wet Glass** : Add a couple drops of soap to bottle with warm water; thoroughly spray glass.
 4. **Remove Backing** : Peel film entirely from backing, starting from corner.
 5. **Place Film** : Place shiny, smooth side of film onto wet glass and position.
 6. **Squeegee** : Spray front of film with water mixture and squeegee out air bubbles.
 7. **Towel Dry** : Finally, wipe top surface of film with a paper towel or cloth to dry.
-

Tips:

- Do not get paper backing wet while on the film.
- Using razor blade to clean the glass will ensure the surface is free of all debris.
- Film will not adhere to any debris or paint and must not touch the frame including the gasket.

Need More Help?

Watch our application instruction video : www.artscape-inc.com

Or call Customer Service : **1.877.729.0708**

Caution! Trim knife is sharp.

¡Precaución! El cuchillo de corte está afilado.

Attention! Le couteau de coupe est tranchant.

Artscape, Inc.
P.O. Box 10165
Portland, OR 97296

Made in China



8 95425 00022 9