
ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET


SKU - N710P330979



Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.


DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

PLEASE DO NOT RETURN TO STORE



Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


Before Installation


Important- Please read these instructions fully before starting assembly

Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.


- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

Cam Lock Assembly Instructions








Identifying the Hardware-Identify the hardware using the illustrations below.





Hardware Lists N710P330979 Α В (0) Ø8x30mm M6x30mm Wood dowel (16pcs) Damping hinge (2 sets) Hex-Head bolt (10pcs) Ε D K4mm M4x20mm Washers (4pcs) Allen key (2pcs) Handle screw (2pcs) G Н))))))> 45*12*1mm 45*17*14mm Ø3x10mm Handle (1pc) Plastic Door Magnet (1 set) Round head screw (6psc) K M accacacacaca(*) Ø3.5x15mm M4x25 Flat head screw (2pcs) Pin shelf (4pcs) Round head screw (4psc) N Anti fall Hardware (2 sets)


















HINGE ADJUSTMENTS



1 Sideways / Tilt adjustment

Turn the screw

clockwise to move the door further away from
the side of the cabinet

anticlockwise to move the door closer to the
side of the cabinet

(2) (4) Height adjustment

While supporting the weight of the door, turn the screws clockwise to move the door up anticlockwise to move the door down

3 Forward and back adjustment

