



BARN DOOR

BOX RAIL - RAIL BRACKET

1. Slide rail bracket onto box rail.
2. Place rail brackets every two feet on box rail.
3. Using rail bracket(s) and box rail as template, drill pilot holes and install using 3/8" lag bolts.

Note: Ensure the brackets are being secured directly into a 2" x 8" header board above door opening.

PUERTA DE GRANERO

SOPORTE DEL RIEL SOBRE EL RIEL DE LA CAJA

1. Deslice el soporte del riel sobre el riel de la caja.
2. Coloque los soportes del riel cada 2 pies (61 cm) sobre el riel de la caja.
3. Utilizando el(los) soporte(s) del riel y el riel de la caja como plantilla, taladre agujeros piloto e instale con tirafondos de 3/8" (1 cm).

Nota: Asegúrese de que los soportes se aseguren directamente en un tablero superior de 2" x 8" (5 cm x 20.3 cm) sobre la abertura de la puerta.

QUESTIONS? | PREGUNTAS?
800.654.8454
MDBUILDINGPRODUCTS.COM

