# Installation Instructions

## Follow these 3 easy steps and you will be ready to enjoy your new shelf.

#### You will need the following tools and materials to hang your mantel shelf:

Bubble Level / Tape Measure / Drill / Pencil / Wall Anchors

#### Step 1: Determine location and measure.

With the shelf upside down on a soft surface, hold the mounting board in position on the mantel shelf. Measure from the bottom of the shelf to the bottom of the mounting board - make note of this measurement, as you will use it in one moment.

Place the shelf on the wall above your fireplace or on the wall at the desired height. Level the shelf and draw a line on the wall along the bottom of the shelf. Remove the shelf and measure up the distance between the bottom of the shelf and mounting board that you noted earlier. Mark the line at several points to ensure a level mount.

Locate and mark the location of the center of 3 studs (2x4 boards) inside the wall you intend to mount your mantel shelf.

## Step 2: Attach the French Cleat hanger board to the wall.

Place the included French cleat mounting board on the wall and line up the bottom of the French cleat mounting board with the upper line. Attach the mounting board to the wall with appropriate fasteners for your application. (See Drawing B)

If you are mounting on a standard drywall over stud construction, make sure you screw the mounting board into the wood studs for strength. When attaching the shelf to a brick surface, you must use a masonry lag bolt.

## Step 3: Mounting the Mantel Shelf

Lift and place the shelf over the mounting board and slide down until the shelf is tight against the wall. Push the shelf tight against the wall and then push down firmly on the shelf to ensure the French cleat is properly connected.

Don't forget to tag us! We would love to see your new mantel. #mantelsdirect



## Installation Instructions

Note: The edge of the shelf against the wall may not be tight against the wall across the whole length of the shelf. The wall may not be uniform and flat. If not, use caulk to fill the gap.



Don't forget to tag us! We would love to see your new mantel. #mantelsdirect

