

# WALL SCONCE

FX-0308BK

INSTALLATION MANUAL

## WARNING:

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODES BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

- \* Check for electric, gas, & plumbing lines before drilling or consult a professional.
- \* Turn off your electricity at the circuit breaker or main fuse box before installation.
- \* Do not restore power to the line until fully installed.
- \* Do not exceed the recommended wattage.
- \* Always allow bulbs to cool for 10 minutes before changing.

This fixture has been rated for up to **three (3) E26 Socket 60-Watt maximum** light bulbs or LED equivalent bulbs (not included).

To avoid the risk of fire, **DO NOT EXCEED THE RECOMMENDED LAMP WATTAGE.**

The lighting fixture is meant for indoor use.

Pls read the installation instructions carefully and follow the steps:

1. Install light bulbs (not included).
2. Attach mounting ring (B) on lamp shade (A). Then fix the mounting ring (B) to socket holder with screws (C).
3. Remove wall bracket (F) from canopy (D). Then attach the wall bracket (F) to junction box (not included) with screws (E) supplied.
4. Make electrical connections using wire nuts (G).
5. Attach the canopy (D) to the wall bracket (F) and screw it by canopy nuts (H).

