

Tools Needed:

Implementos
necesarios:





For warranty info visit
mdbuildingproducts.com

Para obtener información sobre la garantía,
visite mdbuildingproducts.com

BOTTOM PIVOT PIN & JAMB MOUNT BRACKET

1. Remove door by lifting door up and tilting outward.
2. Remove existing bottom jamb bracket from wall and bottom pivot pin from door.
3. Install new bottom pivot pin and jamb mount bracket.
4. Re-install door by inserting top pivot pin and guide roller into bracket and track first, then insert bottom pivot pin into bracket.
5. If necessary, adjust vertical and horizontal alignment using bottom pivot pin.



PASADOR PIVOTANTE INFERIOR Y SOPORTE DE MONTAJE

1. Desmonte la puerta alzándola e inclinándola hacia afuera.
2. Retire el soporte de la jamba inferior existente de la pared y el pasador pivotante inferior de la puerta.
3. Instale el pasador pivotante inferior nuevo y el soporte de montaje de la jamba.
4. Vuelva a instalar la puerta insertando el pasador pivotante superior y el rodillo guía en el soporte y el primer riel, luego inserte el pasador pivotante inferior en el soporte.
5. Si es necesario, ajuste la alineación vertical y horizontal utilizando el pasador pivotante inferior.

Made in China. Hecho en China.

M-D Building Products, Inc.

Oklahoma City, OK 73118

Rev 07/24 mdteam.com

⚠WARNING: Cancer and Reproductive Harm
- www.P65Warnings.ca.gov.

ADVERTENCIA: Cáncer y Daño
Reproductivo - www.P65Warnings.ca.gov.



QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

