

Step-by-step Installation

1



Align the flat surface or opening with the burr of the knockout for easier insertion.

2





Installation without cables:

Insert the fitting into the knockout, from the inside or the outside of the enclosure.

3



For two-cable installation:

Cables may be inserted individually or together.