

Align push plate position,
drill pilot holes, then secure
with 6 screws included.

