



Choose the correct prepped size according to the diameter of the bolts.

Code	For Wood Floors		For Cement Floors	
	Hole Size	DEEP	Hole Size	DEEP
DSIX02	Ø3/16"(5mm)	Ø1-9/16"(40mm)	Ø23/64"(9mm)	Ø1-5/8"(42mm)
DSIX05	Ø5/32"(4mm)	Ø1-3/8"(35mm)	Ø11/32"(8.5mm)	Ø1-5/8"(42mm)
DSIX07	Ø5/32"(4mm)	Ø1-3/8"(35mm)	Ø11/32"(8.5mm)	Ø1-5/8"(42mm)
DSIX08	Ø5/32"(4mm)	Ø1-3/8"(35mm)	Ø11/32"(8.5mm)	Ø1-5/8"(42mm)
DSIX09	Ø1/8"(3mm)	Ø1-3/8"(35mm)	Ø11/32"(8.5mm)	Ø1-5/8"(42mm)
DSIX19	Ø5/32"(4mm)	Ø1-9/16"(40mm)	Ø11/32"(8.5mm)	Ø1-5/8"(42mm)
DSIX26	Ø3/16"(5mm)	Ø1-9/16"(40mm)	Ø23/64"(9mm)	Ø1-5/8"(42mm)
DSIX34	Ø3/16"(5mm)	Ø1-9/16"(40mm)	Ø23/64"(9mm)	Ø1-5/8"(42mm)