

CL-30



INSTALLATION INSTRUCTIONS

Step1: Drill Holes in Cabinet Door or Drawer for screws.

Measure the distance between the 2 posts and drilling 2 holes that distance apart in the selected location. Slip the 8/32 screws through the holes from inside the cabinet door or draw into the posts and tightening.

