

Window Film Instructions

1. Clean any oil or dust from the surface
2. Measure the surface and cut the film with 1 inch additional film on the length and width
3. Spray water on the surface
4. Remove the clear backing starting from the corner while simultaneously applying the film
5. Put pressure from the center out, being careful not to allow air to form between the film and the surface
6. Remove any water and air from the center out using the squeegee
7. Cut the extra film using a knife and ruler

