

Align door stop position where door panel impacts the wall, drill a pilot hole for easy install, then turn the stop clockwise with wrench until hand tight.

