- 1. Before installation, please read the Assembly Instruction carefully.
- 2. Please check whether the Parts and Hardware are consistent with the list.
- 3. It is normal for the sealed environment to smell, not a product quality problem.



Phone number: (909)297-5794/(323)982-8955 service@boyelliving.com Web: www.boyelliving.com

MADE IN CHINA

Page 2 of 16

ASSEMBLY INSTRUCTIONS

	Pa	rt List:			Par	t List:	
ITEM	DESCRIPTION	PART	QTY	ITEM	DESCRIPTION	PART	QTY
1	Top panel		1	7	drawer front		3
2	Bottom panel		1	8	drawer right side		3
3	Left side panel		1	9	drawer left side		3
4	Right side panel		1	10	drawer bottom		3
5	Back panel		1	11	drawer back		3
6	Leg		4	12	drawer baffle		2

MADE IN CHINA

	Hardwar	e List:	
ITEM	DESCRIPTION	PART	QTY
A	Camlock bolt		36
В	Camlock	N X	36
С	Wooden dowel	Φ8*30mm	8
D	Bolt	ω(Φ1/4 ″ *1/2 ″	16
Е	Allen wrench		1
F	Handle		3

Hardware List:							
ITEM	DESCRIPTION	PART	QTY				
G	Machine screw	$\Phi5/32''*1 1/8''$	6				
Н	Back screw	Φ3*12mm	16				
Ι	Safety wall strap		2				
J	Plastic anchor		2				
K	Mounting screw	**************************************	2				
L	Washer	0	2				

- * Required screwdriver & mallet, not included.
- * Before discarding packing materials, please check to make sure that all parts and hardware is present.
- * Two people needed for assembly.
- * Please follow the instructions closely; do not over tighten screws or bolts unless instructed.
- * After a few days from initial assembly, the product may have acclimated to the new environment. Please retighten the hardware.

Screw camlock bolt (A) to wood part.

Do not assemble camlock (B) unless instructed.

To assemble camlock (B), ensure long side of the + is facing the bolt (A) before inserting into hole.



MADE IN CHINA





Page 6 of 16





Page 8 of 16

















To remove the drawer. lift up on the left side buckle and press down on the right side buckle, operatingboth left and right at the same time, and move outward to remove it. Page 16 of 16

