



BARN DOOR

BOX RAIL - BYPASS CONVERSION BRACKET

1. Determine rail mounting positions, loosen bracket from bypass conversion bracket, mount bracket to structure using 3/8" lag bolts. Use one bracket every two feet of rail.
2. Slide rail straps onto rail.
3. Secure straps to bracket.

Note: Ensure the brackets are being secured directly into a 2" x 8" header above door opening.

PUERTA DE GRANERO

SOPORTE DE CONVERSIÓN DE DERIVACIÓN DEL RIEL DE LA CAJA

1. Determine las posiciones de montaje del riel, afloje el soporte del soporte de conversión de derivación, monte el soporte en la estructura utilizando tirafondos de 3/8" (1 cm). Utilice un soporte a cada 2 pies (61 cm) del riel.
2. Deslice las correas de riel sobre el riel.
3. Asegure las correas al soporte.

Nota: Asegúrese de que los soportes se aseguren directamente en un tablero superior de 2" x 8" (5 cm x 20.3 cm) sobre la puerta.

QUESTIONS? | PREGUNTAS?

800.654.8454

MDBUILDINGPRODUCTS.COM

