



**6 Cubic Ft. Black FlexArmor™
Tray
CW383**

**Standard bolt pattern for Chore Warrior Wheelbarrows.
Fits most standard two wheeled wheelbarrows.**

**Some adapters may be needed for other wheelbarrow types.
(Adapters not included)**

Customer service: 651.370.7508
Monday – Friday 8am – 5pm CST
chorewarrior.com

Power Assist Technologies
926 Dale St N
St. Paul, MN 55103

ATTACHING A TRAY

1. Lower a 6 Cu. Ft. plastic tray onto the Chore Warrior frame. Line up all bolt holes in the tray with holes of the Chore Warrior frame brackets.



2. Insert carriage bolts (U) and provided washers through all six bolt holes of tray. These will extend through the tray brace (two) and frame (four). Secure all six bolts with hex nuts. Tighten all nuts with tools. (Carriage bolts & hex nuts not included)

