

elephantrunk parcel drop




Always home. Even when you're not.™

by ARCHITECTURAL MAILBOXES®


Carefully unpack the elephantrunk, parts and hardware.

Hardware and Parts (included)



Tools (not included)

Drill suitable for drilling into masonry or wood



Choose where to locate your elephantrunk


NOTE: The elephantrunk parcel drop is NOT intended to replace a mailbox. Its primary purpose is to receive parcel deliveries.

- The courier must be able to freely access your elephantrunk to make deliveries.
- Choose a protective location, such as on a porch or under an eave, and away from sprinklers.
- You can anchor your elephantrunk to a hardscaped or wooden surface. It will require drilling a hole into the surface, so make sure you pick the right location.

elephantrunk installation


1 Place your elephantrunk at the desired location with the help of another person.

2 Open the bottom door and mark the ground through the hole in the floor.




3 After marking the ground, place the elephantrunk aside before continuing.

4 Drill a hole where you marked the ground:
For hardscape (for example, stone walkway or concrete pad), drill a hole 2.5" deep at the mark with a 5/8" masonry bit.
For wood (for example, deck or porch), drill a pilot hole 2" deep at the mark using a 1/4" wood bit.




5 For hardscape: Remove any debris from the hole and insert the lag shield so it is flush with the surface. Screw the mounting bolt into the lag shield.

For wood: Screw the mounting bolt directly into the surface.




Use the hex portion at the center of the bolt to screw it into the hole.

For both installations, screw it all the way so the hex portion is touching the surface.



6 Carefully screw the four leveling feet into the bottom of each leg about half way.



7 With help, lift the elephantrunk over the installed bolt, aligning the bolt through the hole in the floor. DO NOT secure in place with the mounting knob yet.

8 Level the elephantrunk by adjusting the feet up and down.

9 Place the washer over the bolt and screw on the mounting knob. The knob only needs to be hand tightened.

! Over tightening with a tool may damage the floor and invalidate your warranty.

10 Place the cushion onto the floor over the mounting knob.

11 Open the top door and attach the handle with the two handle screws.


placard installation

1 Remove protective plastic coating from the placard.

2 Write the location of your elephantrunk onto the placard with a permanent marker.

3 Attach the placard to your front entry in a conspicuous location so the courier knows where to deliver your items.

elephantrunk use



Swing down the "No Deliveries" indicator to suspend deliveries.

Incoming drum can accept parcels up to 11.5" x 7.3" x 9.3".

Slide the outgoing partition into the grooves to trap your outgoing parcel for future pickup.

Retrieve your parcels by unlocking the bottom door.

We're all ears!

Give us a call at (310) 374-5700 or email support@architecturalmailboxes.com with any questions.