

## Easy to Install - No Nails, No Mess



### **Cut**

Material is easy to cut with a simple saw.



### **Glue**

Glue with a water-based painter's caulk.



### **Install**

Press into place.



### **Paint**

Finish with a latex-based paint.

**Installation is simple!**

**We recommend starting at your corners.**

**If you are cutting your own corners, refer to the second page for a guide on cutting the angles.**



## How to Miter Queen of Crown Molding In Position

Cutting your crown molding "In Position" refers to cutting it at the angle in which it will be installed. This is recommended for first-timers and for those who will be using a miter box and hand saw.

### Outside 90° Corner Instructions:



### Inside 90° Corner Instructions:

Right Corner Piece: Miter right at 45°



Right Corner Piece: Miter left at 45°



Left Corner Piece: Miter left at 45°



Left Corner Piece: Miter right at 45°



### Tips:

- Both edges of the molding should be flush with the sides of your miter box or saw. This is important for keeping the cuts consistent.
- Not all walls will be structured at a perfect 90° angle. You can adjust your miter angle on a miter saw if necessary.
- Cuts are made with the profile upside down. As you cut, the ceiling side (C) of the profile will be close to you and the wall side (W) will be away from you.

