



AN ORIGINAL GRANITE BRACKET™ PRODUCT

THE ORIGINAL™ INDUSTRIAL FREE HANGING BRACKET



1. Remove drywall from your wall and expose your wall studs. Select your desired height for the brackets. Install additional studs if necessary for your project.



2. Place brackets between 16-20 inches apart, or where wall studs are available. Using the bracket holes as guides, drill pilot holes into your wall studs. After pilot holes have been made, fasten your brackets to the studs with screws. Ensure, brackets are level.



3. Install drywall to your wall studs. Ensure your drywall is cut to fit around your brackets. Cut out a 2.5" wide by 1" deep notch from your drywall with each bracket.



4. Now that your brackets are properly secured and in place, place the countertop of your choice on top of your brackets.



5. Once you have placed the countertop of your choice on your brackets, apply a bead of clear silicone adhesive around your brackets, bonding them to the countertop.



SCAN FOR
MORE PRODUCTS

ORIGINALGRANITEBRACKET.COM | 888-584-1112

*AVAILABLE
IN MULTIPLE SIZES