## Assembly Instruction Sheet #IS-1065P16-4 For Style 1065P16-4 Tools Required: Flathead screwdriver, Phillips screwdriver, pliers, wire cutters, wire strippers, electrical tape, safety glasses. Light Source: (4) E12 Candelabra Base Bulbs 60W Maximum (Not include). Estimated Assembly Time: 20-30 minutes Preparation: Identify and inspect all parts before beginning installation. Check package content list and diagrams below to be sure all parts are present. If any parts are missing or damaged, do not attempt to assemble, Install, or operate the fixture. Contact customer service for replacement parts. A Warnings and Cautions Turn off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt. These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation. Disconnect fixture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool before removal. Package Contents STEP 1 -Install Driver pipe to Fixture Body. - D Socket cover x1 A. Thread the power lord through the Nibble(E) to fix with Fixture body(A).Set the Driver pipe(B) into Nibble(E).Put the Socket sleeve(B),then fix them E Nibble x1 티님 with the loop. F Bobeche x4 LOOP A Fixture Body x1 G 10" Crystal Rods x40 (D)Socket cover B Driver pipe x1 (B)Driver pipe H Celling Canopy x1 **C** Socket sleeve x4 (E)Nibble Hardware Contents Fixture Body(A) PART DESCRIPTION QUANTITY AA **Canopy Lock Ring** 1pcs BB Wire nut 3pcs CC **Canopy Chain Loop** 1pcs DD Crossbar 1pcs 2pcs EE **Outlet Box Screw** AA BB EE CC DD F Figure 1

