

DALTON DAYBED

Model #1393-010 Daybed Side Panels with Tray Model #1393-020 Daybed Back Panel Date: 03-01-2011 Page 1 of 1

Examine all packaging material for small parts that may have come loose during shipment. Periodic checks are recommended to insure that all components are in proper position, tight and free from damage. Keep this assembly instruction for future reference. Adult assembly is required. Customer Service Phone Number: 502-562-0000

HARDWARE LIST PART QTY HARDWARE PART QTY HARDWARE A (12) Allen Bolts (1) Allen Wrench (Ø) C (8) Hex Nuts A 12 В 1 (8) Flat Washers (4) Wood Dowels (1) Open Wrench C D 8 8 PARTS LIST (1) Left Side Panel E G F Н (1) Right Side Panel (1) Back Panel (4) Top Finials (4) Feet FIGURE 1 FIGURE 2 H) (G)Α D The arms on each Side Panel can be opened or closed by lifting upward D and securing with the folding brace on the bottom side. STEP 1 Begin assembly by attaching each Foot (K) to the bottom of each post on the Side Panels (G & H) by firmly screwing each in place. See Figure 1.

STEP 2

Attach the Top Finials (J) to each post on the Side Panels (G & H) by firmly screwing each in place. See Figure 1.

STEP 3

Next, attach the Back Panel (I) to each Side Panel (G & H) by aligning the open holes on the posts with the Wood Dowels (E) and fit in place. Once in place, secure from the outside using 2 Allen Bolts (A) per each outside. Tighten all bolts using the Allen Wrench (B). See **Figure 1**.

STEP 4

Finally, attach the Link Spring Mattress Frame (*Not Included) to each post using 2 Allen Bolts (A) from the outside, 2 Hex Nuts (C) & 2 Flat Washers (D) to secure in place. Tighten all bolts with Open Wrench (F). See **Figure 2**. The assembly is now complete.