
# ASSEMBLY INSTRUCTIONS BATH VANITY-CABINET

SKU - N710P333972




Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and hardware.

Compare with the parts list to be sure all parts are present.

DO NOT TIGHTEN SCREWS UNTIL COMPLETELY ASSEMBLED




Tools Required



IMPORTANT:

PLEASE READ INSTRUCTION BEFORE STARTING THE ASSEMBLY

# PLEASE DO NOT RETURN TO STORE



# Please do not return this product to the retailer!! We are able to assist you in ANY way

If you find that you have any trouble with assembly or missing or damaged parts please contact the seller.


# Before Installation


Important- Please read these instructions fully before starting assembly


Thank you for purchasing this quality product. Be sure to check all packing materials carefully for small parts, which may have come loose inside the carton during shipment. Identify and count all items according to the PARTS LIST and/or HARDWARE LIST shown below. Check you have all the components and tools listed on the following pages.

- We recommend that you assemble this product with the assistance of another person; this will make the assembly easier, and will help eliminate damage to the product or injury to persons during assembly.
- Please do not over tighten screws or bolts until the assembly is completed.
- Keep children and animal away from the work area, small parts could choke if swallowed.
- Please put all parts on a non-abrasive floor before assembly, and follow the assembly steps to assemble your newly purchased product correctly and efficiently.

### **Cam Lock Assembly Instructions**











# SKU - N710P333972 22 Sink - 1pc


### Hardware Lists N710P333972 Α В $\mathsf{C}$ Ø6\*32mm Ø14.5\*9.5mm Ø8x20mm Wood dowel (23pcs) Three in on bolts (22pcs) Three in one locks (22pcs) D Ε (0) (a) M6x30mm M6x45mm Damping hinge (2 sets) Hex-Head bolt (7pcs) Hex-Head bolt (9pcs) G Н ))))))>> Ø3x12mm Washers (13pcs) Pin shelf (3pcs) Round head screw (3psc) K J 45\*12\*1mm 45\*17\*14mm M4x15mm Handle screw (4pcs) Plastic Door Magnet (1 set) Handle (4pcs) M Ν O *@CCCCCCCCCCCCCCCCC(***₹**) Ø3x15mm Ø10x10mm M4x50mm Flat head screw (4pcs) Plastic Canopy (12pcs) Round head screw (12psc) R Q accentance (3) Ø8xØ4\*30mm K4mm Round head screw (15psc) Anti fall Hardware (2 sets) Allen key (1pc)



































## HINGE ADJUSTMENTS



(1) Sideways / Tilt adjustment

Turn the screw clockwise to move the door further away from the side of the cabinet anticlockwise to move the door closer to the side of the cabinet



While supporting the weight of the door, turn the screws clockwise to move the door up anticlockwise to move the door down

Forward and back adjustment

